

# PRODUCT INFORMATION & INSTALLATION GUIDE 2025

Airius Model 60/EC Short AIR PEAR SERIES





464 mm

#### AIR PEAR SERIES - Model 60 EC Short

#### MODEL 60/EC SHORT DIMENSIONS AND PROPERTIES



UNIT SIZESHORTWeight:13 kgsHeight to Rim:404 mmTotal Height:620 mm

Diameter:

MOTOR 230V @ 50 Hz

Watts\*: 143 RPM\*: 1630 L/S\*: 835 m³/hr: 3007

Centre Line Velocity<sup>1</sup>: 2.10 m/s @ 9 m

AMPS\*: 1.30

\*Motor data provided by motor manufacturer and is subject to change at anytime <sup>1</sup>Velocity profile tested in situ

#### **COVERAGE**

#### HEATING

Ceiling Height = 6m - 10m = 12m - 19mFloor area =  $Up \text{ to } 120m^2$  =  $Up \text{ to } 220m^2$ 

All data is indicative only and can change subject to application. For more accurate design please contact Airius Oceania

#### **MOTOR**

Single Phase

Electrically commutated, variable speed 92% efficient motor German EBM Papst EC motor

230 Volt @ 50/60 Hz

#### **NOISE LEVELS**

Sound Power Level = 74 dB(A) Sound Pressure Level @ 3 mts = 53 dB(A) Sound Pressure Level @ 6 mts = 47 dB(A)

Note: A typical free field environment over a reflecting plane. All acoustic testing conducted at 230 Volt, 50Hz and undertaken at the EBM- Papst Acoustic Laboratories in Connecticut USA during August 2014

Please contact Airius for full Noise Testing Report

#### **OPERATING TEMPERATURES**

Min start temp (approx.) =  $-10^{\circ}$  C Min running temp =  $-25^{\circ}$  C Shut off =  $135^{\circ}$  C Reset =  $125^{\circ}$  C

## COLOUR

Off-White, Black or Grey available

#### HOUSING

PC/ABS Resin - Inc. internal fixed blade stator

5VA flame resistance rating

1.8m steel safety leash cable (fastened to housing)

#### **ACCESSORIES & OPTIONS**

Multiple speed control options available:

- Full 0-100% potentiometer speed control option
- Fully programmable Airius touch screen controller
- Airius PearLink WiFi Control

Fully BMS controllable

Bacnet Protocol for individual fan control

#### **INGRESS PROTECTION**

IP44 Rated


#### **WARRANTY**

3 years full manufacturers replacement from date of despatch.



AIR PEAR SERIES - Model 60 EC Short

### **VELOCITY PROFILE**



#### UNIT PLACEMENT

#### **PREPARATION**

Install electrical circuit(s) and outlet(s) in accordance with national and local electric codes.

Outlets should generally be mounted vertically unless a "twist/locking" type is being used.

Wall switch may be installed in circuit to disable power and prevent electrical hazards when servicing.

Confirm electrical continuity of Airius unit on the ground before permanently mounting in the ceiling.

#### **MAINTENANCE**

Frequency of cleaning will vary by application and environment.

You may clean the plastic housing with a damp warm cloth, using mild household detergents.

Do not use petroleum products, thinners or solvents to clean any part of the Airius unit.

If the Airius unit fails, contact manufacturer.

#### **MATERIALS & PROPERTIES**

Constructed from recyclable materials.

The outer shell, stator and fan blades are fire rated 5VA materials.

Power cord is a 1.8m, 3 wire, 1.02 mm diameter 300VAC rated electrical cord - CE/EU compliance rated as HO5VV (PLUG NOT SUPPLIED).

Electrically commutated, variable speed 92% efficient motor.

Motor is thermally protected. Shutoff is at 110°C & reset is at 90°C.

No lubrication required. Bearings are sealed.

#### **OPERATION**

Designed to operate 24 hours-a-day, 7 days-a-week to maintain air circulation/thermal equalization/humidity equalization.

Use optional speed control to fine tune RPM if needed.

#### **INSTALLATION**

Do not hard connect fans in excess of 10 kgs unless agreed with Airius prior to Installation. When attaching it is preferred if some chain or cable is used between fan and the support. However it is not imperative.

For Cooling the Airius fan should be located to suit client's requirements. Suggested locations are from just under the ceiling or closer to the floor to ensure suitable air-cooling flow.

For Heating or Conditioned Spaces the Airius fan should be securely installed as close as possible to the ceiling.

For combination applications fans can be installed close to ceiling or lowered slightly. Contact Airius for design details and assistance.

The Airius unit performs best when air column from the nozzle is unimpeded to the floor.

The Airius unit should not be mounted directly in front of heat ducts, vents or any other high heat source.

Use professionally installed hardware, capable of supporting a minimum of five times the weight of the fan unit.

Hardware to hang the unit includes but is not restricted to: Hooks, chains, cables, carabiners, bridle rings, beam clamps and bolts.

Density of the placement is directly related to the effectiveness, performance and savings.

Mount out of reach from people and animals.


Floor plans, mezzanines, office locations, machinery, people placement, plumbing, lighting, duct work, electrical systems, natural light/air systems, cranes, doors, windows, ventilation and fire suppression systems are all factors in properly locating the Airius system within the ceiling.



## AIR PEAR SERIES - Model 60 EC Short

## **CHAIN HUNG (STRAIGHT)**

#### PLUG NOT SUPPLIED




NOTE: Do not hard connect any Airius model 60 fans to structure - use chain (preferred) or cable only



AIR PEAR SERIES - Model 60 EC Short


## **CHAIN HUNG (ANGLED)**







## **BMS CONTROL WIRING**



#### **GENERAL NOTES**

0-10 V signal allows infinitely variable open loop speed control

Connecting the red and yellow leads will allow EC fans to operate at full speed  $\,$ 

A single controller can be used to control multiple fans with the same speed setting

The BMS generates this voltage to send to the signal (yellow)

Yellow is labelled as 0-10VDC because that is the acceptable range of voltages that the fan will accept

